





LCD-006-3

- 1.To take off the plastic cover available by hand or by a Flat-Head screwdriver.
- 2.Available to WRENCH NO.13 to tighten or loose the nylon nut to adjust the gradient.



Item	Spare parts	Q'ty
1	LCD MOUNT ASSEMBLY 76mm	2
2	LCD MOUNT ASSEMBLY 82mm	1
3	JOINT	1
4	FROMARM	1
5	FIXED TUBE	1
6	BASE	1
7	SCREW CAP 5/16"-18UNC*L5/8"	4
8	SPRING WASHER ϕ 5/16"	3
9	WASHER ϕ 8* ϕ 13	3
10	NYLON NUT 5/16"-18UNC	3
11	WASHER ϕ 12.5* ϕ 25*T=3	3
12	INSULATING CLAMP	1
13	SCREW M4*P0.7*L12mm FOR LCD	12
14	WRENCH NO.13	1
15-1	ALLEN WRENCH NO.4	1
15-2	ALLEN WRENCH NO.6	1

