


WARN:
Loose the steel sheet U
NUT to adjust angle,
if necessary.

Screwed over
steel sheet U NUT.



OH01

Item	Spare parts	Q'ty
1	RIGHT BOTTOM TUBE	1
2	LEFT BOTTOM TUBE	1
3	EXTENSION TUBE B	1
4	SCREW BH 3/8"-16UNC*L58mm	5
5	NYLON NUT 3/8"-16UNC	4
6	SPRING WASHER $\phi 3/8"$	1
7	WASHER $\phi 3/8"$	8
8	WAHSER $\phi 9.5 \times \phi 45$	1
9	WHEEL	4
10	FEDESTAL	1
11	EXTENSION TUBE A	1
12	BACK PLASTIC COVER	1
13	PLASTIC COVER	2
14	MATCHED PLATE	1
15	FIXED PLATE	2
16	WASHER $\phi 8.5 \times \phi 25 \times T=3$	2
17	NYLON NUT $\phi 5/16"-18UNC$	2
18	SCREW CAP 5/16"-18NUC*L3/4 WITH 2 WASHERS	6

